



Scumed srl

Via Giuseppe Di Vittorio 307/3

20099 Sesto San Giovanni (MI)

T: 02 24 05 451/2/3 - F: 02 24 09 472

www.scumed.it - info@scumed.it

PI IT00774350961 - CF 04239450150

ANTI-RUST

Usage information:

This product is an ideal additive to mix with the deionized water of EDMs.

Recommended solution 0.5% (1 lt. For 200 lt. Of water)

It does not produce pollution, does not alter deionization, filtration, nor does it corrode the valves.

The use prevents the formation of rust on the pieces and does not produce any effect on the water system.

The division between pure water and impure water, possibly in a water basin, is excellent. It does not increase conductivity.

Preparation:

Shake the product (heavier than water) in a container with a few liters of water. Then distribute as specified above.

